




Diagram illustrating the components of the overload protection device:

- PROTECTIVE COVER
- BALE STRAP
- OVERLOAD LEAD SCREW
- OVERLOAD
- OVERLOAD SPRING
- HOUSING WELD JOINT

A detailed cross-sectional diagram of the overload protection assembly. The diagram shows the internal components of the housing, including the protective cover, bale strap, overload lead screw, overload adaptor, overload spring, and the housing weld joint. The assembly is shown in a cross-section view, revealing the internal mechanical parts and their arrangement within the housing.

PROTECTIVE COVER

BALE STRAP

OVERLOAD LEAD SCREW


OVERLOAD ADAPTOR
3/4 OVERLOAD ONLY

OVERLOAD SPRING


HOUSING
WELD JOINT

WARNING- WIRING DIAGRAM MUST BE FOLLOWED
AS SHOWN. ANY MISWIRING CAN CAUSE SERIOUS
ELECTRICAL HAZARD AND POTENTIAL DAMAGE OR
RUPTURE OF COMPONENT ELECTRICAL PARTS.

1. ASSEMBLE THESE PARTS AS SHOWN IF SPECIFIED ON B/M.
2. IDENTIFIED CONDUCTOR MAYBE WHITE OR RIBBED (115 VOLT ONLY-NEUTRAL).
3. COMPRESSOR UNIT GROUND SCREW IS NOT PROVIDED BY T.P.CO.



ALTERNATE RELAY - HOOKUP DOES NOT
CHANGE WHEN THESE RELAYS ARE USED.



115 OR 230 V.-SCHEMATIC WIRING DIAGRAM - CSIR - CURRENT RELAY
(REF. DWG. MD472-9)

AJ - 115 OR 230 VOLT - CSIR - CURRENT RELAY

A.

ENGLISH	
Q.A. SYMBOLS	
☆	= CATEGORY I
△	= CATEGORY II
□	= CATEGORY III
	= CATEGORY IV

[illegible]