



ⓑ COMPRESSOR UNIT GROUND (SCREW IS NOT PROVIDED BY T.P. CO.)

AV-230 V. -PSC-INTERNAL OVERLOAD (LINE BREAK) - START WINDING HEATER - CRANKCASE HEATER.
AV-230 V. -CSR OR CSR START CAPACITOR ASSIST-INTERNAL OVERLOAD (LINE BREAK) START WINDING HEATER - CRANKCASE HEATER.

ALTERNATE IF CONDUIT IS USED.

PSC SHOWN

230 VOLT CRANKCASE HEATER

NOTE:
1. ASSEMBLE PARTS AS SHOWN IF SPECIFIED ON B/M.
2. IF TWO RUN CAPACITORS ARE REQUIRED HOOK-UP AS SHOWN.

Ⓒ AIR CONDITIONING MODELS AV

ENGLISH	
Q. A. SYMBOLS	
☆	= CATEGORY I
△	= CATEGORY III
□	= CATEGORY IIII
○	= CATEGORY IV

DIS. CODE		NAME		ELECTRICAL HOOK-UP	
DWN. T.G. 2/5/93		TEC		THIS PRINT SUPERSEDES ALL PRINTS PRIOR TO	
MATERIAL		DRAWING No. M0888-08		REVISION LEVEL: REL	
DRAWING No. M0888-08		REVISION LEVEL: REL		DRAWING NO. DEAV3	