



AV-230 V. -PSC-INTERNAL OVERLOAD (LINE BREAK) - START WINDING HEATER - CRANKCASE HEATER.
AV-230 V. -CSR OR CSR START CAPACITOR ASSIST-INTERNAL OVERLOAD (LINE BREAK) - START WINDING HEATER - CRANKCASE HEATER.

ALTERNATE IF CONDUIT IS USED.

PSC SHOWN

NOTE:

1. ASSEMBLE PARTS AS SHOWN IF SPECIFIED ON B/M.
2. IF TWO RUN CAPACITORS ARE REQUIRED HOOK-UP AS SHOWN.

Ⓜ AIR CONDITIONING MODELS

| | |
|--------------|---------------|
| ENGLISH | |
| Q.A. SYMBOLS | |
| ☆ | CATEGORY I |
| △ | CATEGORY III |
| □ | CATEGORY IIII |
| ○ | CATEGORY IV |

| | | | | | |
|--|------------------|---|---|--|---|
| DTD #242040-000 3A ADDED NOTE 03APR03 V #235662 5C ADDED NOTE 4/10/97 U #231516 REVISE AND REDRAWN ON CAD | | DATE CHANGE LT LC | THIS DRAWING OR PRINT IS THE PROPERTY OF SHERMAN IAV-DEAV1. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF SHERMAN IAV-DEAV1. THE USER SHALL BE RESPONSIBLE FOR OBTAINING NECESSARY PERMITS AND APPROVALS FROM THE APPROPRIATE AGENCIES AND AUTHORITIES. SHERMAN IAV-DEAV1 SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES, ARISING FROM THE USE OF THIS DRAWING OR PRINT. THE USER SHALL BE RESPONSIBLE FOR OBTAINING NECESSARY PERMITS AND APPROVALS FROM THE APPROPRIATE AGENCIES AND AUTHORITIES. SHERMAN IAV-DEAV1 SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES, ARISING FROM THE USE OF THIS DRAWING OR PRINT. | | DIS. CODE NAME ELECTRICAL HOOK-UP |
| DWG. T.G. CK. G. APR. | SCALE 1" = 1" | THIS PRINT SUPERSEDES ALL PRINTS PRIOR TO | | | |
| MATERIAL | | DRAWING NO. DEAV1 UG1101SKS:1 SHERMAN IAV-DEAV1 V01_V-C.PRT REVISION LEVEL: REL | | | |