


--NOTES--




1. ASSEMBLE PARTS AS SHOWN IF SPECIFIED ON B/M.
2. IF TWO CAPACITORS ARE REQUIRED HOOKUP AS SHOWN.



--NOTES--

1. ASSEMBLE PARTS AS SHOWN IF SPECIFIED ON B/M.
2. IF TWO RUN CAPACITORS ARE REQUIRED HOOKUP AS SHOWN.

WARNING - WIRING DIAGRAM MUST BE FOLLOWED AS SHOWN. ANY MISWIRING CAN CAUSE SERIOUS ELECTRICAL HAZARD AND POTENTIAL DAMAGE OR RUPTURE OF COMPONENT ELECTRICAL PARTS.



230 VOLT-SCHEMATIC WIRING DIAGRAM-PSC-INTERNAL OVERLOAD (LINE BREAK)-START WINDING HEATER

REF. DWG. MD472-33

AW-230 V.-PSC-INTERNAL OVERLOAD(LINE BREAK)-START WINDING HEATER
AW-230 V.-CSR OR CSR START CAPACITOR ASSIST-INTERNAL OVERLOAD (LINE BREAK)-START WINDING HEATER

Q.A. SYMBOLS

AW

230 VOLT SCHEMATIC WIRING DIAGRAM-CSR OR CSR START CAPACITOR ASSIST-INTERNAL OVERLOAD (LINE BREAK)-START WINDING HEATER

REF. DWG. MD472-34

REV	DATE	BY	CHKD	DESCRIPTION
1	4/16/97	SJS	HINMAN	ADDED NOTE
2	01/30/97	HINMAN	REDRAWN NO CHANGE	
3				
4				
5				
6				
7				
8				

DIS. CODE	NAME	SCALE	THIS PRINT SUPERSEDES ALL PRINTS PRIOR TO
3482	ELECTRICAL HOOKUP	1"=1"	
TECUMSEH PRODUCTS CO. TECUMSEH, MICHIGAN			
MATERIAL			
INTERNAL USE ONLY UGIDISK6(SHERMAN)AW-DEAW0108-C.PRT			
PART NO. DEAW1			